




## Quick Tips

### Making your smartphone or tablet easier to use


Here are some tips on how to make your smartphone or tablet easier to use:

1. **Customise your settings** – within the Settings app on your device you can adjust the brightness of the screen, change your ringtone and volume, and select a different background for your home screen.


Find the settings - usually it's an icon that looks like a cog:



To make your phone easier to use have a look at the settings for your display, sounds and home screen.



- 2. Display Brightness** – If the brightness of your device is too low, you may strain your eyes. This is also possible if your screen is too bright. As a rule, the brightness of your screen should be similar to the surrounding light. If you are outdoors in the sunlight, it may help to increase brightness of your device. Where there is low lighting you could consider reducing the brightness
- 3. Make the text size bigger** – on most devices the text size or “font size” can be adjusted. This can be done through the Settings app. Font or Text size is usually found under “Display & Brightness” or “Display” in the Settings app.



- 4. Make use of “Simple” or “Easy” Mode** if you see this as an option in your display settings. “Simple” or “Easy” mode simplifies navigation on your smartphone by increasing the size of your on-screen items, preventing accidental touches and providing a high-contrast keyboard.
- To make **apps easier to find on the screen** you should consider using a plain background for your Home screen.
- 6. Delete apps you don’t use** – this will make your device’s home screen less cluttered. To delete an app just tap and hold the app icon until it wobbles, then drag to the bin symbol or select the ‘remove app’ option that appears either at the top or bottom of the screen.

Note: Most devices come with several apps pre-installed. Some pre-installed apps cannot be deleted.

- 7. Move apps around** – move your most frequently used apps to the home screen. This will make them easier to find.

Note: To move an app just hold the app icon until it wobbles, then slowly drag the app to where you want it. Remove your finger from the screen when you have placed the app where you want it.